



HOW TO MEASURE FOR SHEEP WAGON COVER

1. Measure from bottom edge of overhang--over top of wagon bows to the bottom edge of overhang on the other side.
2. Measure closest distance from corner of door to top edge of wagon bows.
3. Measure length from front edge of front wagon bow to back edge of back wagon bow.
4. Measure closest distance from corner of window to top edge of wagon bow.
5. (For wagon covers with canvas ends.) Measure from bottom edge of overhang to highest point of wagon bows.
6. (For wagon covers with end walls) Measure the width of the wagon box.

